




**NOTE: TEMPLATES ARE NOT IDENTICAL**

1. Cut out the templates and position them on the front side of the corresponding lens. The arrow should point towards the edge of the lens.

2. Drill  marks 5/32" and test fit the LED panel before final mounting.

**1983-87 BUICK REGAL/GN**

**HOUSING DRILL TEMPLATES**

**PN 1100886-6**

**DIGI-TAILS**  
DIGITAL TAILLIGHTS

WEB: [WWW.DIGI-TAILS.COM](http://WWW.DIGI-TAILS.COM) PHONE: 856.719.9989 EMAIL: [INFO@DIGI-TAILS.COM](mailto:INFO@DIGI-TAILS.COM)

